

**Limited Warranty:** Tub Refinishing, Inc. DBA Munro Products or Munro Bath Systems as follows; this warranty is in lieu of all other written or unwritten, expressed or implied warranties, and Tub Refinishing, Inc. DBA Munro Products or Munro Bath Systems expressly disclaims any warranty of merchantability or fitness for a particular purpose. The buyer assumes all risks whatsoever as to the use of the material. Keep away from children, animals or persons that are sensitive to paint or fumes. Fumes can be harmful to humans and animals and are can be flammablepoison.

**Safety: A protective respirator can be worn if available. Use product with adequate ventilation. Always use rubber gloves.**

Tub Refinishing, Inc DBA Munro Products or Munro Bath Systems is not responsible for accidents or misuse of these products or parts and materials of this kit. Safety is in the hands of the user. If you are unsure about the use or safety of this product please return the unopened and unused kits to the supplier. Do not return goods without receiving a Return Materials Authorization (RMA) number from Munro Products. All returned goods are at the purchasers cost. Opened or used materials will be refused for credit. See all MSDS Sheets which are provided and are also available via our websites.

**Suitability for use:** The user is responsible for establishing that these products are suitable for the user's application and that all requirements for meeting approvals, standards, codes, deposal, use and regulations of any kind are satisfied. Distributor denies any responsibility for establishing suitable of use; where, when, and how the materials from this kit are used. Read all information and instruction before use of this product. Use Caution!

*Tub Refinishing, Inc. DBA Munro Products, Munro Bath Systems, and BathWorks™. BathWorks™ is an exclusive trademark of this company.*

# BATHWORKS

Tub, Tile, Wall Surround, & Sink Repair Kit

## CHIP REPAIR INSTRUCTION MANUAL

### Chip Repair Application

**Step 1:** Pick or Dremal away loose matter and taper the edges with a sharp-edged utility knife.

**Step 2:** Mix three (3) parts **Chip Filler** with (1) part **Cream Hardener**. Stir mixture thoroughly with applicator stick. Patch must be used within two (2) minutes. \*ONLY MIX what's needed. The remaining unmixed products can be saved for later use.

**Step 3:** Liberally apply patch compound to repair area with stir stick or Razor blade. Patch will not respond to surface below 65F. Using a heat gun or hair dryer will speed dry time considerably.

**Step 4:** Once patch has completed its cure, the patch will be hard to the touch. After the patch has cured, sand area dry or wet with 120 grit sandpaper until flush with surrounding area. Repeat step 2 & 3 if necessary.

---

**Recomendation:** After completing the chip repair, you'll want to seal the repaired area with the BathWorks Touch-Up Paint Kit.

Visit **www.Bath-Works.net** for the Touch-Up Paint Kits and other bathtub car products.