

**Limited Warranty:** Tub Refinishing, Inc. DBA Munro Products or Munro Bath Systems as follows; this warranty is in lieu of all other written or unwritten, expressed or implied warranties, and Tub Refinishing, Inc. DBA Munro Products or Munro Bath Systems expressly disclaims any warranty of merchantability or fitness for a particular purpose. The buyer assumes all risks whatsoever as to the use of the material. Keep away from children, animals or persons that are sensitive to paint or fumes. Fumes can be harmful to humans and animals and are can be flammablepoison.

**Safety: A protective respirator can be worn if available. Use product with adequate ventilation. Always use rubber gloves.**

Tub Refinishing, Inc DBA Munro Products or Munro Bath Systems is not responsible for accidents or misuse of these products or parts and materials of this kit. Safety is in the hands of the user. If you are unsure about the use or safety of this product please return the unopened and unused kits to the supplier. Do not return goods without receiving a Return Materials Authorization (RMA) number from Munro Products. All returned goods are at the purchasers cost. Opened or used materials will be refused for credit. See all MSDS Sheets which are provided and are also available via our websites.

**Suitability for use:** The user is responsible for establishing that these products are suitable for the user's application and that all requirements for meeting approvals, standards, codes, deposal, use and regulations of any kind are satisfied. Distributor denies any responsibility for establishing suitable of use; where, when, and how the materials from this kit are used. Read all information and instruction before use of this product. Use Caution!

*Tub Refinishing, Inc. DBA Munro Products, Munro Bath Systems, and BathWorks™. BathWorks™ is an exclusive trademark of this company.*

# BATHWORKS

Tub, Tile, Wall Surround, & Sink Repair Kit

## REPAIR PAINT INSTRUCTIONS

### Repair Paint Application

**Step 1:** Clean the area to be painted (repaired) with provided alcohol pad.

**Step 2:** If the surrounding area has any high spots or ridges use 220-grit wet/dry sandpaper and water to sand completely flush. Make sure ALL edges are completely smooth.

**Step 3:** Apply the base coat of color in light coats, allowing each to dry before applying another. Don't worry about getting the color solid on the first shot. The idea here is to build up thin layers of paint that will even out as you lay them down. Once you've applied an adequate amount of touch up paint, allow the paint to dry overnight.

**Step 4:** Once patch has completed its cure, the patch will be hard to the touch. Allow to sit for 24 hours.

---

**Recomendation:** If the touch up paint doesn't appear perfect it's alright. Allow the paint to harden for a few days. Then apply rubbing compound to the entire area. Follow the compound's directions to ensure a smooth, shiny finish.

Visit [www.Bath-Works.net](http://www.Bath-Works.net) for all Refinishing Kits and other bathtub care products.

**Limited Warranty:** Tub Refinishing, Inc. DBA Munro Products or Munro Bath Systems as follows; this warranty is in lieu of all other written or unwritten, expressed or implied warranties, and Tub Refinishing, Inc. DBA Munro Products or Munro Bath Systems expressly disclaims any warranty of merchantability or fitness for a particular purpose. The buyer assumes all risks whatsoever as to the use of the material. Keep away from children, animals or persons that are sensitive to paint or fumes. Fumes can be harmful to humans and animals and are can be flammablepoison.

**Safety:** A protective respirator can be worn if available. Use product with adequate ventilation. Always use rubber gloves.

Tub Refinishing, Inc DBA Munro Products or Munro Bath Systems is not responsible for accidents or misuse of these products or parts and materials of this kit. Safety is in the hands of the user. If you are unsure about the use or safety of this product please return the unopened and unused kits to the supplier. Do not return goods without receiving a Return Materials Authorization (RMA) number from Munro Products. All returned goods are at the purchasers cost. Opened or used materials will be refused for credit. See all MSDS Sheets which are provided and are also available via our websites.

**Suitability for use:** The user is responsible for establishing that these products are suitable for the user's application and that all requirements for meeting approvals, standards, codes, deposal, use and regulations of any kind are satisfied. Distributor denies any responsibility for establishing suitable of use; where, when, and how the materials from this kit are used. Read all information and instruction before use of this product. Use Caution!

*Tub Refinishing, Inc. DBA Munro Products, Munro Bath Systems, and BathWorks™. BathWorks™ is an exclusive trademark of this company.*

# BATHWORKS

Tub, Tile, Wall Surround, & Sink Repair Kit

## REPAIR **PAINT** INSTRUCTION MANUAL

### Repair Paint Application

**NOTE:** Only use enclosed touch up paint if NOT refinishing the tub

**Step 1:** Wipe the repair and surrounding area clean using the alcohol preps provided.

**Step 2:** Shake Repair Paint thoroughly. Carefully unscrew repair paint brush cap.

**Step 3:** Dip Brush into Repair Paint. Lightly stroke repair. Lightly feather edges. **MUST DRY 24 HOURS BEFORE USE!**

**Visit [www.Bath-Works.net](http://www.Bath-Works.net) for all Refinishing Kits and other bathtub care products.**