

Bathworks®

SPRAY-ON REFINISHING KIT INSTRUCTIONS

IMPORTANT:

Please read through the instructions carefully before starting project
Scan the QR code inside this booklet to find helpful project tutorial videos!

SUPPLIES INCLUDED

- Aerosolized Refinishing Paint Cans (20oz/ea)
- Comfort Hand Grip
- Instructions (with Safety Warnings & Care Tips)

RECOMMENDED SUPPLIES (NOT INCLUDED)

- TSP/Comet®/Ajax®
- Protective Surface Coverings
- Blue Painters Tape
- Paper Towels & Tack Cloth
- Razor Blade or Scrapers
- Latex/Rubber Gloves
- Garbage Bag
- Any other items you may feel necessary depending on your situation.
- Steel Wool/Sandpaper (120 grit)
- Hair Dryer or Wet-Vacuum
- Ventilator Fan
- Respirator
- Protective Eyewear
- 100% Silicone Caulk

For all cast iron, steel, & ceramic fixtures - **Bathworks® EZ Etch Kit** is strongly recommended.
If unsure, do not paint, and return kit unopened.

COVERAGE

Bathtub Only Kits needed		Bath + 6' Surround Kits needed	
1	Standard Tub	2	
2	Large Tub	2	
2	Corner Tub	3	

One kit covers two standard sink basins.

Some applications may require two coats.

SAFETY & CLEAN UP

Liquid products found within this kit are **solvent-borne** and are **highly flammable**. Care should be taken to avoid the inhalation of spray mist or vapors, as well as contact between the wet paint and exposed skin or eyes. Always keep work areas well ventilated and wear **personal protective equipment - respirator, eyewear, & gloves**. Keep away from flame, children, animals, and individuals sensitive to fumes. **Always ensure nearby surfaces are covered and protected**. Cleaning solvent for this paint is **Lacquer Thinner** or a similar substitute. In the event of spills, ensure that Lacquer Thinner is appropriate and safe to use on intended surfaces as there's a risk of serious and permanent damage to surfaces such as linoleum, plastics, wood and anything previously painted. See additional **safety notes** at the end of this document.

DIRECTIONS

NOTE: *This kit may be used for bathtubs, tile, wall surrounds, sinks, & more!*

STEP 1: Clear the tub of all personal items. Make sure there is positive air-flow and adequate ventilation in the work areas at all times.

CLEAN TUB THOROUGHLY! Scrub bathtub with Ajax® or Comet® while focusing on areas with heavy soap buildup - use steel wool if needed.

NOTE: *ANY soap residue present will prevent bonding and cause failure.*

OPTIONAL: *Use a razor blade or sharp scraper to remove the caulk around the bathtub or walls. You may or may not elect to do this dependent upon individual situations. Not necessary, but recommended.*

STEP 2: With a single edge razor blade, scrape down the bathtub thoroughly. Focus on areas under the soap tray and drain area. Wipe all scrapings and foreign materials into a garbage bag. Keep this bag for debris nearby while working on this project.

NOTE: *NEVER place tools or scrapers directly on unprotected surfaces such as toilet seat covers, counter tops, or linoleum floors.*

STEP 3: Wear protective gloves and eyewear. Using Comet® or Ajax® - mix with enough warm water to make a paste and apply over the entire surface. Scrub the bathtub or walls thoroughly with a Scotch-Brite® pad or sponge with the etching cleaner mixture.

STEP 4: Rinse the surface well after scrubbing. Water may be used from the bathtub or a bucket of water. While the bathtub or walls are still damp, sand the surface entirely using 120 grit sandpaper. Rinse well after.

STEP 5: Place a glove or a plastic bag over the tub spout and shower head to ensure water does not drip onto the surface while undergoing resurfacing. Using a blow dryer or strong wet-vacuum, blow water out of drain and wall areas. When the surfaces are completely dry, use blue painters tape to mask off walls around the bathtub and tub drain.

NOTE: *Drying surfaces completely, especially at the drain, is critical to the success of the refinishing coating. ANY moisture while resurfacing may result in product and bonding failure.*

NOTE: *Any repairs, if needed, should be completed prior to using a tack cloth.*

STEP 6: Using a tack cloth, rub over the entire surface in an effort to remove all foreign materials from the areas. The bathtub or wall surfaces should now be smooth, completely cleared, and ready to be sprayed with the refinishing product.

CAUTION: *In the following steps - proper ventilation, gloves, and eye wear are strongly recommended. Use all paint products with caution. For best results, use when can is between 50°F - 90°F (10°C - 32°C.)*

PROTECT & COVER ALL NEARBY SURFACES: INCLUDING, BUT NOT LIMITED TO, FLOORS, WALLS, CEILING, COUNTERTOPS, TOILETS, & FIXTURES. *Aerosolized paint has the potential to travel and coat nearby surfaces within the work area. Please use with caution.*

User is responsible and liable for any overspray outside of intended surfaces.

STEP 7: Shake can for at least one minute after rattle is heard and occasionally during use.

STEP 8: Remove cap from the **Aerosolized Paint Can**. Attach the provided **Comfort Hand Grip** to one of the spray cans by first tilting the front of the grip downward into the ridge on the top of the can so the spray nozzle is inside the space on the grip. You may need to use another hand to add stability and rotate the grip around the can to find a spot in the ridge where the grip will take. Next, use downward and forward force on the hand holding the grip to get the other side of the holder to snap into place in the ridge of the can. Ensure the spray nozzle is facing outwards in line with the hand grip by rotating either the can or the grip. Once the grip is locked into place, the spray can is ready to be used.

NOTE: *Using the **Comfort Hand Grip** is critical to ensuring paint is applied consistently, smoothly, and evenly. Without using the grip, you will experience hand and finger fatigue, which will result in inconsistent coverage.*

STEP 9: While holding the grip, ensure nozzle is facing away from you, point the can at intended surface and pull the trigger on the grip to start spraying the surface. Make sure to use even and steady strokes while holding the can at a distance of 6in - 8 in (15cm - 20cm) away from intended surface.

NOTE: *If clogging develops, turn spray nozzle 1/4 turn or remove and clean spray nozzle slot. **DO NOT** stick pins or any other object into can opening. With can spray nozzle pointed away from you, reinsert spray nozzle with a gentle, twisting motion. To clear spray nozzle for future use, turn can upside down and spray for 3 seconds.*

OPTIONAL: *A second coat may be applied right away following the same spraying pattern. Ensure that you do not lean on wet surfaces.*

NOTE: *Dispose of all unused materials and debris immediately after completing the project. Obey all state, city, & town codes for proper paint disposal. See "Safety" section at the end of these instructions for more details.*

STEP 10: After allowing the coating to set for 45 minutes, carefully remove the tape by pulling at a 45 degree angle. Surfaces will be dry to the touch in about 1 hour. Please allow refinished surfaces to dry **24 hours** before use. If caulk was removed before resurfacing, reapply using 100% Silicone caulk once surfaces are dry. Allow caulk to dry, and rinse refinished surfaces with warm water before use.

THANK YOU FOR CHOOSING

Bathworks®

REFINISHING PRODUCTS

We want to hear about your experience!

Please scan the QR code below with the camera app on your smartphone to find links to our product listings to leave a review on the platform you purchased your kit from.

If you're pleased with the results.. tell others!
If not, tell us!

We welcome any questions and provide troubleshooting for concerns on any project.

Give us a call at **1.800.872.8827**
Or email us at **info@munroproducts.com**



Please enjoy **10%*** off your next total purchase made on our website:

bath-works.net

Using coupon code:

DIY10

*Standard exclusions apply. 10% off total Bathworks® order. Offer valid only at <https://www.bath-works.net>. May not be used in conjunction with any other coupon. Employees not eligible for discount. This offer may be modified by Tub Refinishing Inc, DBA Munro Products, in its sole discretion without notice at any time.

SURFACE CARE TIPS

Congratulations!

Your bathtub or bath fixture has just been resurfaced with the finest product in the tub and tile coating industry.

Follow these care tips to maintain the beauty of your surface.

GENERAL TIPS

- Treat as if this is a brand new bathtub; remove excess water and wipe dry after each use.
- Always be certain faucets are tightly closed and the shower pipe is drained after each use.
- **DO NOT** rest any soap bottles, spray cans, or wet clothes on the surface for extended periods of time.
- **NEVER** use hair dye in a refinished bathtub.
- If bathing pets in the bathtub, always place a towel down to prevent scratches.

BATHMATS

- If you do not have the non-slip system applied to your surface and you find it to be too slippery, you may use a NON-SUCTIONED bathmat or a towel (these must be picked up after each use.) Do not hang the mat or towel over the bathtub.
- **Use of a suctioned bathmat or stick-on strips will cause failures of the resurface coating.**

CLEANING

- Even though the bathtub does not look dirty, it should be cleaned at least once a week with a liquid **NON-ABRASIVE** cleaner (Scrubbing Bubbles®, 409®, or Fantastic® are recommended products.)
- **NEVER** use bleach or abrasive cleaners (Ajax®, Comet®, or Soft Scrub®) on a refinished surface. If the non-slip protection system is applied to the bottom of your bathtub, you may use Soft Scrub® on that area if needed.
- **DO NOT** use Mr. Clean Magic Eraser® on your refinished surface. This is a micro-abrasive sandpaper sponge and will damage your coating over time with repeated use.

Remember

If you treat your new surface with respect, clean it regularly, and keep your taps dry - your tub will stay beautiful and radiant for years to come! Use **Bathworks® Cleaner and Polishing Kit** for the ultimate shine and protection!

LIMITED WARRANTY

Tub Refinishing, Inc. DBA Munro Products as follows; this warranty is in lieu of all other written or unwritten, expressed, or implied warranties, and Tub Refinishing, Inc. DBA Munro Products expressly disclaims any warranty of merchantability or fitness for a particular purpose. The buyer assumes all risks whatsoever as to the use of the material. Keep away from children, animals, or persons that are sensitive to paint or fumes. Fumes can be harmful to humans and animals, and can also be flammable.

SAFETY

A protective respirator should be worn if available. Use product with adequate ventilation. Always use rubber gloves. Tub Refinishing, Inc. DBA Munro Products is not responsible for accidents or misuse of these products or parts and materials of this kit. Safety is in the hands of the user. Keep all refinishing kit materials and tools away from children, animals, and individuals sensitive to paint or fumes. Some items in this kit are flammable and should be disposed of properly in accordance to local state, city, & town codes regulating used paint products. Use all paint products with caution. **DO NOT** dispose of paint or clean tools by using water and flushing down household drains - these are solvent-borne products and may potentially damage pipes & the environment. Use **Lacquer Thinner** or comparable cleaner for cleaning tools & spills. Lacquer Thinner is capable of permanently damaging surfaces such as linoleum, plastic, wood, and previously painted surfaces. Never use Lacquer Thinner on skin and use gloves & eyewear while using. If you are unsure about the use or safety of this product, please return the unopened and unused kits to the supplier. All returned goods are at the purchaser's cost. Opened or used materials will be refused for credit. See all **Safety Data Sheets (SDS)** which are available via our website: **bathworks.net**

SUITABILITY FOR USE

The user is responsible for establishing that these products are suitable for the user's application and that all requirements for meeting approvals, standards, codes, disposal, use, and regulations of any kind are satisfied. Distributor denies any responsibility for establishing suitability of use; where, when, and how the materials from this kit are used. Read all information and instruction before use of this product. Use caution.

FOR EMERGENCY: CHEMTREC® 1-800-424-9300



**America's #1 Choice in Bathroom Restoration
For Over 50 Years!**

**Find us on Facebook & Instagram at
bathworks.kits**

*Tub Refinishing, Inc. DBA Munro Products, and Bathworks®.
Bathworks® is an exclusive trademark of this company.*

**bath-works.net
info@munroproducts.com
1.800.872.8827**